



Рисунок 1-Габаритные и присоединительные размеры.

*Гарантийное пломбирование
**Консервационное пломбирование

Таблица 2-Габаритные и присоединительные размеры

Размеры в мм

Типоразмер электронасоса	L	I	I ₁	I ₂	I ₃	I ₄	B	b	b ₁	b ₂	b ₃	b ₄	H	h ₁	h ₂	h ₃
KM50-32-125	500	195	100	70	100	145	200	190	140	50	125	165	218	112	140	80
KM50-32-125a	475															
KM65-50-125	546	229	100	70	112	166	250	210	160	50	160	205	270	112	140	100
KM65-50-125a																
KM65-50-160	580	229	100	70	140 112	166	250	230	190	50	160	205	270	132	160	100
KM65-50-160a	550															
KM80-65-160	635	241	100	70	140	171	300	265	212	50	190	230	300	160	180	112
KM80-65-160a																
KM80-65-160b	600	229	100	70	178	193	360 350	265	212	70	254 216	320 258	420 310	160	200	160
KM80-50-200	793	301														
KM80-50-200a	713	282	100	70	178	193	350	280	212	70	254 216	320 258	420 300	160	210	160
KM100-80-160	793	301														
KM100-80-160a	715	282	125	95	178 118	193	350	280	212	70	254 216	320 258	420 300	160	210	160
KM100-80-160b	640	246														
KM100-65-200	1000	301	125	95	241 203	193	400	320	250	70	279	355	455	180	225	180
KM100-65-200a	960															
KM100-65-250	990	326	160	120	305 267	193	415	360	280	70	318	400	480	200	250	200
KM100-65-250a																
KM150-125-250	863	301	160	120	210 178	193	445	400	315	90	254	320	420	250	355	160
KM150-125-250a	818															

Продолжение таблицы 2

Типоразмер электронасоса	D	D ₁	D ₂	D ₃	D ₄	D ₅	Dy ₁	Dy ₂	d	d ₁	d ₂	g ₁	g ₂	g ₃	g ₄	n	n ₁	a
КМ50-32-125	90	110	140	78	100	135	50	32	14	10	14	16	19	14	9	4	4	80
КМ50-32-125а																		
КМ65-50-125	110	130	160	102	125	160	65	50	14	12	14	16	20	15	10	4	4	80
КМ65-50-125а																		
КМ65-50-160	122	145	180	102	125	160	65	50	14	12	18	20	20	15	10	4	4	80
КМ65-50-160а																		
КМ80-65-160	133	160	190	123	145	180	80	65	14	12	14	22	20	15	10	4	4	100
КМ80-65-160а																		
КМ80-65-160б	133	160	195	102	125	160	80	50	14	15	18	22	20	15	20	4	4	100
КМ80-50-200																		
КМ80-50-200а	158	180	215	133	160	195	100	80	14	15	18	22	22	16	20	8	4	100
КМ100-80-160																		
КМ100-80-160а	158	180	215	122	145	180	100	65	14	15	18	22	20	15	22	8	4	100
КМ100-80-160б																		
КМ100-65-200	158	180	215	122	145	180	100	80	14	15	18	22	24	15	25	8	4	125
КМ100-65-200а																		
КМ100-65-250	158	180	215	122	145	180	100	65	18	19	18	22	24	15	25	8	4	125
КМ100-65-250а																		
КМ150-125-250	212	240	280	184	210	245	150	125	18	15	22	26	26	20	20	8	8	140
КМ150-125-250а																		

Начальник ЦНС *Мася*. В.И. Шабаков